

## How to setup the V6 Plus via ConfigTool NEO

To use the V6 Plus to control your smart home with AIO CREATOR NEO, you have to configure the device with the ConfigTool NEO for your home network. If you want to use the gateway with IQONTROL NEO, you do not need the ConfigTool NEO. You can instead [set it up with IQONTROL NEO directly](#).

The current versions of ConfigTool NEO and AIO CREATOR NEO are available at: <https://www.mediola.com/service#downloads>

### How to set up your V6 Plus with ConfigTool NEO:

1. First connect the V6 Plus to your router using a LAN cable.
2. Connect the V6 Plus to a power source.

Make sure your V6 Plus is on the same network as your PC.

3. Now start the ConfigTool NEO.
4. The V6 Plus should be displayed directly.

If the V6 Plus is not displayed, click the “Refresh” button at the bottom left until it is displayed.



The V6 Plus was found. An IP address was automatically assigned to the gateway. The gateway is ready to be [integrated into AIO CREATOR NEO](#).

From:

<http://doku.mediola.com/> - **Dokumentationen**

Permanent link:

<http://doku.mediola.com/doku.php?id=en:v6:v6plus-inbetriebnahme>

Last update: **2020/06/24 11:21**

